

# Adding Passives Tracers to MPAS-Atmosphere Simulations

With the background about MPAS software from the previous presentation, adding a passive tracer to an MPAS-Atmosphere simulation is *relatively* easy!

There are two steps to accomplish this:

1. Define initial conditions for the tracer when running the `init_atmosphere_model` program
2. Define the tracer in the model itself
3. If you'd like, add sources/sinks

## Setting initial conditions

When setting initial conditions for the passive tracer (let's call it radon), we need to first define this field in the `Registry.xml` file of the `init_atmosphere` core

- All scalars (whether moisture or passive) are defined in an array of variables called “scalars”

```
<var_array name="scalars" type="real"
    dimensions="nVertLevels nCells Time">
    <var name="qv"          array_group="moist"/>
    <var name="qc"          array_group="moist"/>
    <var name="qr"          array_group="moist"/>
    <var name="radon"       array_group="passive"/>
</var_array>
```

In the model, the `array_group` is used to identify, e.g., moisture species that contribute air density; instead of “passive”, we could use any name other than “moist”

## Setting initial conditions

Inside the `init_atmosphere` core, the `mpas_init_atm_cases.F` code is responsible for defining initial conditions

- We can add a new subroutine here to initialize “radon”

```
type (mpas_pool_type), intent(inout) :: state

integer, pointer :: index_radon
real (kind=RKIND), dimension(:,:,:), pointer :: scalars

call mpas_pool_get_array(state, 'scalars', scalars)
call mpas_pool_get_dimension(state, 'index_radon', index_radon)
```

Using pools, we can access the 3-d “scalars” array that was defined in the `Registry.xml` file, and we can figure out which index in this array contains “radon” (rather than, e.g., “qv” or “qc”)



## Setting initial conditions

Now, using whatever clever logic we would like, we can set the “radon” component of the “scalars” array:

```
scalars(index_radon, :, :) = 0.12345
```


In general, we can initialize the tracer in one of many ways:

- Horizontally interpolate from some other dataset
- Set the tracer based on geographic location, (lat, lon)
- Set the tracer based on terrain height or land use category
- Etc.

## Setting initial conditions

Once we've added code to set the values in `scalars(index_radon, :, :)` we will need to re-compile the `init_atmosphere` core

Creating initial conditions as usual, we should now have “radon” in our initial conditions file in addition to “qv”, “qc”, and “qr”!



*Left: A simple checkerboard pattern is a nice way to test a passive tracer*

## Adding the tracer to the model

We have produced initial conditions for the “radon” tracer, but without changes in the `atmosphere_model` program, the model will simply ignore “radon” in the initial conditions file

- We need to edit the `Registry.xml` file for the atmosphere core, too!

```
<var_array name="scalars" type="real"
           dimensions="nVertLevels nCells Time">

    <var name="qv" array_group="moist" units="kg kg^{-1}"
        description="Water vapor mixing ratio"/>

    <var name="qc" array_group="moist" units="kg kg^{-1}"
        description="Cloud water mixing ratio"
        packages="bl_mynn_in;bl_ysu_in;cu_tiedtke_in;mp_kessler_in"/>

    <var name="radon" array_group="passive" units="kg kg^{-1}"
        description="Radon mixing ratio"/>

</var_array>
```

*Above: A subset of the “scalars” variable array in the atmosphere core Registry.xml file. The model definition of “scalars” is a little more complicated...*

## Adding the tracer to the model

Note several new things:

- Individual scalar constituents have *packages*
- The units of most scalars are  $\text{kg kg}^{-1}$

```
<var_array name="scalars" type="real"
           dimensions="nVertLevels nCells Time">

  <var name="qv" array_group="moist" units="kg kg^{-1}"
      description="Water vapor mixing ratio"/>

  <var name="qc" array_group="moist" units="kg kg^{-1}"
      description="Cloud water mixing ratio"
      packages="bl_mynn_in;bl_ysu_in;cu_tiedtke_in;mp_kessler_in"/>

  <var name="radon" array_group="passive" units="kg kg^{-1}"
      description="Radon mixing ratio"/>
</var_array>
```

*Above: A subset of the “scalars” variable array in the atmosphere core Registry.xml file. The model definition of “scalars” is a little more complicated...*

## Adding the tracer to the model

Based on what we did in the `init_atmosphere` core, you may be tempted to think we are done editing the `Registry.xml` file

It turns out that in the model itself, we also need to define an array to hold the tendency for the new tracer

- This is done in a variable array named `scalars_tend`

```
<!-- scalar tendencies -->  
<var_array name="scalars_tend" type="real"  
           dimensions="nVertLevels nCells Time">  
  
    <!-- we will see on the next slide what goes here... -->  
  
</var_array>
```

## Adding the tracer to the model

One might expect that the units for the radon tendency would be  $\text{kg kg}^{-1} \text{ s}^{-1} \dots$

```
<var_array name="scalars_tend" type="real"
    dimensions="nVertLevels nCells Time">
    <var name="tend_qv" name_in_code="qv" array_group="moist"
        units="kg m^{-3} s^{-1}"
        description="Tendency of water vapor mass per unit volume
divided by d(zeta)/dz"/>


    <var name="tend_radon" name_in_code="radon" array_group="passive"
        units="kg m^{-3} s^{-1}"
        description="Tendency of radon mass per unit volume divided
by d(zeta)/dz" />
</var_array>
```

... but what we actually need is for the units of the radon tendency to be  $\text{kg m}^{-3} \text{ s}^{-1}$ .

## Considerations for sources and sinks

If we don't specify sources/sinks for our new passive tracer, it will simply be transported by MPAS, and it will have no impact on the rest of the simulation

- I.e., all other prognostic fields should be the same whether the passive tracer is present or not!





## Considerations for sources and sinks

But, we can specify sources/sinks if we like...

- As with the tracer and its tendency, we will need to define the source/sink field in the `Registry.xml` file of the model

```
<var name="radonten" type="real"  
      dimensions="nVertLevels nCells Time"  
      units="kg m^{-2} s^{-1}"  
      description="Radon gas areal production rate" />
```

The source/sink field can be a regular variable in the `Registry.xml` file – there's no need to add it to any special place like a scalars variable array

The units of the source/sink can be whatever is needed. We will only need to convert these units to  $\text{kg m}^{-3} \text{s}^{-1}$  when applying the source/sink!



## Considerations for sources and sinks

Where can we apply the sources/sinks for our passive scalar?

- If time-invariant, the simplest would be to specify them in the initialization routine for MPAS, `atm_core_init(...)`

```
call mpas_pool_get_array(tend_physics, 'radonten', radonten)
call mpas_pool_get_array(sfc_input, 'ivgtyp', ivgtyp)
```

```
radonten(:, :) = 0.0_RKIND
do iCell=1,nCells
  ! Assume that vegetation category 16 is water
  ! (true for USGS land use, not true for MODIS)
  if (ivgtyp(iCell) == 16) then
    ! 1 g/m^2/day destruction over water
    radonten(1,iCell) = -0.001 / 86400.0
  else
    ! 2 g/m^2/day production over land
    radonten(1,iCell) = 0.002 / 86400.0
  end if
end do
```


## Considerations for sources and sinks

Regardless of how we get the source/sink field, we need to set the tracer tendency based on this field in the `physics_get_tend(...)` routine

```
!
! Account for sources and sinks for radon (in the radonten array)
! in the tendency for radon. If radonten has units of kg/m^2/s,
! we need to divide by layer thickness and then by d(zeta)/dz
! to get the proper units of kg/m^3/s divided by d(zeta)/dz for
! The tendency.
!
do i = 1, nCellsSolve
  do k = 1, nVertLevels
    tend_scalars(index_radon,k,i) = tend_scalars(index_radon,k,i) &
      + radonten(k,i) / (zgrid(k+1,i) - zgrid(k,i)) / zz(k,i)
  end do
end do
```

# Considerations for sources and sinks

All of this work pays off, though!



In summary, there are several pieces to adding a new passive tracer in MPAS-Atmosphere:

1. Define the tracer in the `init_atmosphere` core's `Registry.xml` file
2. Provide initial conditions for the tracer
3. Define the tracer in the `atmosphere` core's `Registry.xml` file
4. Define the tracer tendency in the `atmosphere` core's `Registry.xml` file
5. Optionally, define sources/sinks for the tracer
  - These may be programmatically specified, or read from a periodic input stream